



WES silencer fitting instructions

Where the muffler fits directly onto the steel tail pipe (no O-rings used), use a silicon sealing compound to act as seal and insulator.

Check absorption packing frequently. Repack if contaminated with oil, carbon, etc. Repack evenly and firmly. Packing in good condition maintains top performance.

When dismantling silencer cap, just loosen the bolts with oval shaped holes and dismount completely the other bolts. With the help of a mallet hit softly the heads of the loosened bolts sideways and slide out the silencer cap.

Use only WES mufflerpac for your WES silencer